



Warmcote is a dry readymixed feebly hydraulic lime plaster for internal or external use.

FULL BAG MIXING INSTRUCTIONS:

- Pour no more than 14 litres of clean water into a large (60 litre+) tub or bin.
- From the small paper bag, disperse all of the fibres into the water thoroughly, stirring with a stick.
- Gently add Warmcote, mixing with a plasterer's paddle, do not add all of the dry plaster at once, bring gradually up to the required consistency. If necessary, add more water.
- There is no 'right or wrong' amount of water to add, Warmcote can be used at whatever consistency best suits the job, be it thinned down for spraying or thick enough to pack in deep fill repairs.
- Once the Warmcote is uniformly mixed, it does not need to stand, it can be used straight away.
- Ensure that the background is clean and free from loose friable or dusty material.
- Warmcote can be used for the full thickness of plaster from dubbing out to a polished finish in one, two or multiple coats on most backgrounds, it also works very well as a scratch coat beneath a Limecote finish. We would not however recommend its use as a finish on timber frames or backgrounds where background movement is a factor, a finish coat of Limecote would however be perfect.



Lincolnshire Lime

01469 531 227
07743 362 408
Lincolnshirelime.co.uk